Dr. Volker Paschmann, 3M Automotive Division

PSA in Action Acrylic Foam Tapes in Dialogue with Painted OEM Surfaces



a New Future






What? The Introduction

Technology

Platful

Clear Coats – Dialogue Partner I




- 1. Metal
- 2. Pretreatment (e.g. Zink)
- 3. e-Coat
- 4. Primer-Surfacer
- 5. Base Coat
- 6. Clear Coat

Corrosion Protection Corrosion Protection Stone Chip Performance Colour and Effects Gloss and Resistances




PSA – Dialogue with Clear Coats: Applications I






PSA – Dialogue with Clear Coats: Applications II























PSA – Dialogue with Clear Coats










How? The Technlogy

Technology

Platful

Adhesive Systems






PSA Acrylic Foam Tapes – Dialogue Partner II

- Self Stick Adhesive in Uniform Layer Thicknes
- The Core / "Carrier Material" is 100% Adhesive
- Pressure optimizes Adhesion to Surface
- NO Activation by Heat, Energy etc...
- Constant Physical Properties @ Normal Conditions









PSA Acrylic Foam Tapes – Dialogue Partner II

Kaelble (3M), Dahlquist (3M), Yarusso (3M)

Main Feature is Thickness of Core Adhesive Material



PSA – Adhesion on Clear Coats: Mechanism







Stress Distribution/Stress Release

Elasticity



12 3M Confidential.

Viscosity




Technology Platful

Why? The Task

PSA – Adhesion on Clear Coats: Peel Adhesion Test


90 ° Peel Adhesion





PSA – Adhesion on Clear Coats: Peel Process

Simplified Model




Kaelble (3M), Dahlquist (3M), Yarusso (3M)



Force in N

PSA – Adhesion on Clear Coats: Peel Process I


smooth peel



Original measurement with 3M AFTs



PSA – Adhesion on Clear Coats




AFM – pictues, side = 0,005 mm

Even smaller modifications in the clear coat leads to different surface properties

-> large difference in adhesion performance possible!








Originalmessung mit 3M AFTs



PSA – Adhesion on Clear Coats: Master Curves



Apparatus: Oscillation Rheometer z.B. ARES / 25 mm PP


Stress: Oscillation 0.1Hz – 30Hz

Temperature: -50°C – 150°C

Realx. time: 5 min


Strain: 5%

The Challenge






The Answer!





PSA – Constructions



Self Stick

w/ 1 skin adhesive Single Sided w/ 2 skin adhesives Double Sided





Technology Platf

Really? The Proof

Paint Change @ OEM – Standard Tape

	90°	n painted panel 90 n. @ RT		eel Adhesion on pai after 72 hrs @ F			
	Plant A CC 1	Average of 3 samples N/cm		Failure Mode	Average of 3 s N/cm	Failure Mode	
	BC 1.1		14,2		23,5		
	BC 1.2		14,8		21,6	POP	
	BC 1.3	-	110		22 0		
	BC 1.4	Таре	Condition	Average	Failure Mode		PUP
	BC 1.5			N/cm			
		Таре	< 2min.	20,3	S/POP		
	Plant B	New			5/POP	amples	Failure
	CC 2	Generation					Mode
	BC 2.1	BC 2.7	20 min. 24 h.	45,3	50%FS		
	BC 2.2						
	BC 2.3			44,2	100%FS		
	BC 2.4		24 11.	44,2			
	BC 2.5	25,6			36,8		
	BC 2.6	25,6		POP	37,0	POP	
	BC 2.7		27,9 26,8 27,6 28.4		39,1		
	BC 2.8				37,7		
	BC 2.9				38,3		
	BC 2.10				37,2		
25	BC 2.11		26,5	3M	39,0		D
20					-) -		Re Re

PSA – Applikcation on Carbamate and 2K Clear Coats

Substrate w/ 1K Carbamate	GT 6012	GTI 6512	GTE 6212	GTE 6112	PT 1100	EX 4011
90° Peel Adh.: 20 min @ RT (N/cm)	6	11	14	12	19	43
90° Peel Adh.: 72 h @ RT (N/cm)	8	13	16	13	24	44
Substrate w/ 2K nano Particle CC	GT 6012	GTI 6512	GTE 6212	GTE 6112	PT 1100	EX 4011
90° Peel: 20 minutes (N/cm)	12	18	20	14	44	44
90° Peel: 72 h RT (N/cm)	18	21	21	18	52	44



Paint Change 2K -> 2K nano Particle

Substrate w/ 2K	GT 6012	GTI 6512	GTE 6212	PT 1100	EX 4011
90° Peel: 20 min (N/cm)	13	22	36	43	41
90° Peel: 72 h RT (N/cm)	16	24	29	49	44
Substrate w/ 2K nano Particle CC, V2		GTI 6512	GTE 6212	PT 1100	EX 4011
90° Peel 20 min RT (N/cm)		11	14	11	20
90° Peel 72 h RT (N/cm)		13	16	23	31





Technology Platf

And? The Link



Thanks a lot

for your attention!